mqtt_disconnect

WMMEGA FW >= 2.1161

Disconnect the current MQTT connection

Description

mqtt_disconnect ( )

This function disconnects the current MQTT connection, allowing you to resubscribe in case of a connection issue.

Parameters

None

Return Values

None

Example

```
<?
  mqtt_disconnect();
?>
```

See Also

mqtt_publish() - Publish a message to MQTT

mqtt_subscribe() - Subscribe to MQTT messages

mqttstat() - Get the MQTT connection status

getusbstat() - Get USB host status information

From:
http://wattmon.com/dokuwiki/ - **Wattmon Documentation Wiki**

Permanent link:
http://wattmon.com/dokuwiki/uphp/functions/mqtt_disconnect?rev=1631512652

Last update: **2021/09/13 05:57**