mqttstat

WMMEGA FW >= 2.1161

Get MQTT connection status

Description

mqttstat ( )

Parameters

None

Return Values

Array of the following values

Key	Value
CONNECTED	1 if connected or 0 if disconnected
IDLE	1 if idle or 0 if busy

See Also

mqtt_subscribe() - Subscribe to an MQTT channel

mqtt_publish() - Publish to an MQTT channel

mqtt_disconnect() - Disconnect from MQTT

From:
http://wattmon.com/dokuwiki/ - **Wattmon Documentation Wiki**

Permanent link:
http://wattmon.com/dokuwiki/uphp/functions/mqttstat?rev=1574673161

Last update: **2021/09/13 05:56**