

debug

WMPRO FW > 1.0 WMMEGA FW > 2.0

Print to debug output

Description

`debug (string $str)`

Parameters

str: A string to output

Return Value

None

Example

```
<?
debug("This is a debug message");
//this will appear on the serial port if connected to a console
?>
```

See Also

[serial_port_programming](#) - Some information on connecting and using the serial port

[debugout\(\)](#) - Enable or disable debug messages

[error_reporting\(\)](#) - Set the debug output level

[log\(\)](#) - Print to the System Log

[print\(\)](#) - Output data to the current output stream such as a web page or terminal

From:

<http://wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**

Permanent link:

<http://wattmon.com/dokuwiki/uphp/functions/debug?rev=1487604234>

Last update: **2021/09/13 05:56**

