

ftp_open

WM-MINI2, WM-MEGA FW >= 2.1137 WM-M2 FW >= 3.1137

Open a connection to an FTP server

Description

```
int ftp_open ( string $host , int $port , string $username , string $password [, int  
$secure ])
```

Connect to the server and return the response code.

Parameters

\$host: **String** containing the host name or IP address of teh FTP server

\$port: **Int** FTP port number

\$username: **String** containing the FTP username

\$password: **String** containing the FTP password

\$secure: **Int** whether to use TLS (1) or not (0)

Return Values

int: Returns 1 if FTP connection was successful and 0 if it failed.

Example

```
<?  
    $res = ftp_open("ftp.myserver.com",21,"myuser","mypassword");  
    if ($res) {  
        print("connected to FTP server!!");  
        ftp_close();  
    }  
?>
```

See Also

[ftp_close\(\)](#) - Close an FTP connection

From:

<http://wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**



Permanent link:

http://wattmon.com/dokuwiki/uphp/functions/ftp_open?rev=1561791548

Last update: **2021/09/13 05:56**