

mem_dump

WMPRO, WMMINI FW >= 1.0 WMMEGA FW >= 2.0

Write the current memory map to /dump.txt

Description

mem_dump ()

Parameters

None

Return Values

None

Example

Create or overwrite the file /dump.txt

```
<?  
    mem_dump();  
?>
```

See Also

[mem_usage\(\)](#) - Write memory usage to standard output

[freemem\(\)](#) - Return free memory space

[Memory Limit Challenges to Programming the Wattmon](#)

[nvram_dump\(\)](#) - Dump the contents of NVRAM to standard output

[print_r\(\)](#) - Dump the contents of an array to the current output

From:

<http://wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**

Permanent link:

http://wattmon.com/dokuwiki/uphp/functions/mem_dump?rev=1536156211

Last update: **2021/09/13 05:56**

