

# mem\_dump

WMPRO, WMMINI FW >= 1.0 WMMEGA FW >= 2.0

Write the current memory map to /dump.txt

## Description

mem\_dump ( )

## Parameters

None

## Return Values

None

## Example

**Create or overwrite the file /dump.txt**

```
<?  
    mem_dump();  
?>
```

## See Also

[mem\\_usage\(\)](#) - Write memory usage to standard output

[freemem\(\)](#) - Return free memory space

[Memory Limit Challenges to Programming the Wattmon](#)

[nvram\\_dump\(\)](#) - Dump the contents of NVRAM to standard output

[print\\_r\(\)](#) - Dump the contents of an array to the current output

From:

<http://wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**

Permanent link:

[http://wattmon.com/dokuwiki/uphp/functions/mem\\_dump?rev=1631512652](http://wattmon.com/dokuwiki/uphp/functions/mem_dump?rev=1631512652)

Last update: **2021/09/13 05:57**

