

mqttstat

WMMEGA FW >= 2.1161

Get MQTT connection status

Description

mqttstat ()

Parameters

None

Return Values

Array of the following values

Key	Value
CONNECTED	1 if connected or 0 if disconnected
IDLE	1 if idle or 0 if busy

See Also

[mqtt_subscribe\(\)](#) - Subscribe to an MQTT channel [mqtt_publish\(\)](#) - Publish to an MQTT channel
[mqtt_disconnect\(\)](#) - Disconnect from MQTT

From:

<http://wattmon.com/dokuwiki/> - Wattmon Documentation Wiki

Permanent link:

<http://wattmon.com/dokuwiki/uphp/functions/mqttstat?rev=1574670810>

Last update: **2021/09/13 05:56**

