

strtolower

WMPRO, WMMINI FW >= 1.0 WMMEGA FW >= 2.0

Return the lowercase version of a **string**

Description

string strtolower (**string** \$str)

This function converts all alphabetic characters in **str** to lowercase

Parameter

\$str: The input **string**

Return Values

Lowercase **string**

Example

```
<?
  $str="Mary Had A Little Lamb and She LOVED It So";
  $str=strtolower($str);
  print $str; // Prints "mary had a little lamb and she loved it so"
?>
```

See Also

[charat\(\)](#) - Return the ASCII code for a character in a **string** at an index

[strlen\(\)](#) - Return the length of a **string**

[strpos\(\)](#) - Return the position of the first occurrence of a needle in a haystack

[strrpos\(\)](#) - Return the position of the last occurrence of a needle in a haystack

[strtoupper\(\)](#) - Return the UPPERCASE version of a **string**

[substr\(\)](#) - Return a sub-string of the passed str from start for len characters. If len is blank it will return the string until the end.

[ucfirst\(\)](#) - Convert a **string** to lowercase except for the first character of each word

From:

<http://wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**

Permanent link:

<http://wattmon.com/dokuwiki/u.php/functions/strtolower?rev=1495813063>

Last update: **2021/09/13 05:56**

