

net_enable3g

WMPRO, WMMINI FW >= 1.0 WMMEGA FW >= 2.0

Enable 3G support for the dongle

Description

net_enable3g ()

This enables the 2G/3G PPP stack which will automatically connect to the Internet once the dongle is plugged in

Parameters

None

Return Values

None

Example

```
<?  
net_enable3g();  
?>
```

See Also

[net_disable3g\(\)](#) - Disable 3G support for the dongle

[usb_info\(\)](#) - Get information about the USB state

[setusbpower\(\)](#) - Enable or disable USB power

[getusbstat\(\)](#) - Get USB host status information

From:

<http://wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**

Permanent link:

http://wattmon.com/dokuwiki/uphp/functions/net_enable3g

Last update: **2021/09/13 05:57**

