

setusbpower

WMPRO, WMMINI FW >= 1.0 WMMEGA FW >= 2.0

Enable or disable USB power

Description

setusbpower (int \$state)

This function will turn on or off the power for USB. This can be used to reset a USB dongle or just to disable it if required.

Parameter

\$state:

- **1** - Enable USB power
- **0** - Disable USB power

Return Values

None

Example

```
<?
  setusbpower(0);
?>
```

See Also

[get3gstat\(\)](#) - Get cellular data connection status information

[net_disable3g\(\)](#) - Disable 3G support for the dongle

[net_enable3g\(\)](#) - Enable 3G support for the dongle

[getusbstat\(\)](#) - Get USB host status information

From:

<http://wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**

Permanent link:

<http://wattmon.com/dokuwiki/uphp/functions/setusbpower>

Last update: **2021/09/13 05:57**

