

# mb\_queue\_command

WMPRO, WMMINI FW >= 1.0 WMMEGA FW >= 2.0

Queue a sequence of characters to the RS-485 bus and get but ignore the reply

## Description

`array` mb\_queue\_command ( `mixed $values` [, `mixed $values ...` ] )

## Parameters

**\$values**: Characters to send, `array` or `integer`

## Return Values

`Array` of `numbers`

## See Also

[mb\\_add\\_dev\(\)](#) - Add a device to the list of polled devices

[mb\\_delete\\_dev\(\)](#) - Delete a device from the list of active devices

[mb\\_get\\_dev\\_by\\_id\(\)](#) - Return modbus device details by ID

[mb\\_get\\_dev\\_by\\_index\(\)](#) - Return modbus device details by index

[mb\\_get\\_dev\\_by\\_name\(\)](#) - Return modbus device details by name

[mb\\_get\\_dev\\_info\(\)](#) - Return modbus device details by type

[mb\\_get\\_role\\_array\(\)](#) - Return an `array` of all roles and their values

[mb\\_get\\_status\\_by\\_role\(\)](#) - Return status of the device attached to the role

[mb\\_get\\_val\\_by\\_role\(\)](#) - Return value of the role

[mb\\_num\\_devices\(\)](#) - Return number of devices on the modbus

[mb\\_scan\\_complete\(\)](#) - Check to see if a modbus scan has completed

[mb\\_scan\\_percent\(\)](#) - Return scan percentage completed

[mb\\_send\\_command\(\)](#) - Send a sequence of characters to the RS-485 bus and get a reply

[mb\\_set\\_dev\\_var\(\)](#) - Set a variable on a modbus device

[mb\\_set\\_val\\_by\\_role\(\)](#) - Set a role value on a modbus device

[mb\\_start\\_scan\(\)](#) - Initiate an automatic scan of the modbus

From:

<https://www.wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**

Permanent link:

[https://www.wattmon.com/dokuwiki/uphp/functions/mb\\_queue\\_command](https://www.wattmon.com/dokuwiki/uphp/functions/mb_queue_command)

Last update: **2021/09/13 05:57**

